

# OZZ XO1 P

88105 (black)

88106 (white)

## Before installation

1. Check the local laws and regulations and the region your vehicle may travel to for Auxiliary light before installation, ensure they are compliance.
2. Read all installation instructions.
3. Make sure the dimension and weight of the lamps and device are matched to your vehicle see figure 01.
4. Slight moisture inside may exist, it will be removed from the vent after 2-4 time working.
5. Working Voltage: 10-32V.

## Mounting

1. Drill 8.5 mm holes for screw placement on the surface where you would like to fix the light.
2. Use the bolt to fasten the lamp, add the locking washer and tighten the bolt.
3. Illustration of multi mounting options: side bracket and bottom bracket.

## Wiring connections & Functions

1. Wiring connections

Black: Ground,-  
 Red: Driving light,+  
 White: White position light,+  
 Yellow: Amber position light,+  
 Blue: R65 function,+  
 Green: warning pattern switch,+

2. Wiring Harness, 40A relay, 30A fuse.

*Please note: The warranty is void if the product is mounted upside down.*

**Figure 01**

